

Multicast streaming in ImagineWorldClient software

The settings about how to connect device from the PC Imagineworldclient in multicast mode, you can operate as the following instruction:

First, enter the ImagineworldClient software, and add the encoder, after that, click “option”,---choose “sever management”---

Then will be appear the “server assignment” window---right click “camera” which is under the encoder---choose “camera setting”---

And then appear the new small window, choose the “Transmission Mode”---“Multicast”---click “OK”

As the following illustration

